

ACK TECHNOLOGIES INC.

MODEL E-04 ELT INSTALLATION MANUAL OPERATION MANUAL

THE CONDITIONS AND TESTS REQUIRED FOR TSO APPROVAL OF THIS ARTICLE ARE MINIMUM PERFORMANCE STANDARDS. IT IS THE RESPONSIBILITY OF THOSE DESIRING TO INSTALL THIS ARTICLE ON A SPECIFIC TYPE OR CLASS OF AIRCRAFT TO DETERMINE THAT THE AIRCRAFT INSTALLATION CONDITIONS ARE WITHIN THE TSO STANDARDS. THE ARTICLE MAY BE INSTALLED ONLY IF FURTHER EVALUATION BY THE APPLICANT DOCUMENTS AN ACCEPTABLE INSTALLATION AND IT IS APPROVED BY THE ADMINISTRATOR.

APPROVALS

FAA /TRANSPORT CANADA

TSO C-126

TSO C-142a

TSO C-91a

EASA

ETSO 2C126

ETSO 2C91a

ETSO C142a

COSPAS/SARSAT

T.001

T.007

INDUSTRY CANADA

1863A-E04AF



P/N E04M REV DATE 01/12/2011
Rev 1.5 PRINTED IN THE USA

IMPORTANT VISIT OUR WEBSITE WWW.ACKAVIONICS.COM FOR THE LATEST SERVICE BULLETINS AND INSTALLATION INFORMATION BEFORE STARTING THE INSTALLATION.

TABLE OF CONTENTS

SECTION 1	406 MHz ELT OVERVIEW
SECTION 2	ELT INSTALLATION
SECTION 3	ANTENNA INSTALLATION
SECTION 4	REMOTE MONITOR INSTALLATION
SECTION 5	AUDIO ALERT INDICATOR INSTALLATION
SECTION 6	GPS INTERFACE INSTALLATION
SECTION 7	FINAL INSTALLATION AND CHECKOUT
SECTION 8	REGISTRATION
SECTION 9	OPERATION AND SELF TEST
SECTION 10	PERIODIC MAINTENANCE / CONTINUING AIRWORTHINESS
SECTION 11	LITHIUM BATTERY REPLACEMENT / HAZMAT SHIPPING INFORMATION
SECTION 12	SPECIFICATIONS
SECTION 13	PROGRAMMING PROCEDURE
SECTION 14	WARRANTY PROCEDURE
SECTION 15	ENVIRONMENTAL QUALIFICATIONS
SECTION 16	CANADIAN MAINTENANCE REQUIREMENTS

SECTION 1 406 MHz ELT OVERVIEW

THE MODEL E-04 121.5/406 MHz ELT IS DESIGNED FOR USE IN AIRCRAFT USED FOR GENERAL AND COMMERCIAL AVIATION. OLDER GENERATION ELT'S WERE VERY LIMITED IN THEIR ABILITY TO RAPIDLY LOCATE, AND IDENTIFY A DOWNED AIRCRAFT.

OFTEN IT TOOK SEVERAL PASSES OF THE ORBITING SATELLITES TO GET AN APPROXIMATE FIX ON A DOWNED AIRCRAFT. THE OLDER GENERATION ELT'S GAVE RESCUERS NO INFORMATION ON TYPE OF AIRCRAFT, OWNER/OPERATOR, OR CONTACT INFORMATION. THE NEW GENERATION 406 MHz ELT'S PROVIDE MUCH BETTER, AND FASTER LOCATION ACCURACY. ALONG WITH PROVIDING INFORMATION TO SEARCH AND RESCUE ORGANIZATIONS ABOUT THE AIRCRAFT TYPE, OWNERSHIP, AND EMERGENCY CONTACT INFORMATION. LOCATION ACCURACY WITH OLDER GENERATION ELT'S WAS LIMITED TO ABOUT A 15 - 20 MILE RADIUS, AND COULD TAKE SEVERAL HOURS TO PROVIDE ACCURATE LOCATION DATA. FOR NEW GENERATION 406 MHz ELT'S WITHOUT GPS POSITION INFORMATION, THE AVERAGE TIME TO

PROCESS AND IDENTIFY THE AIRCRAFT LOCATION IS 1-2 HOURS, WITH A SEARCH RADIUS OF ABOUT 2 MILES OR LESS. WITH GPS INFORMATION, THE TIME TO LOCATE THE AIRCRAFT POSITION IS 10 MINUTES OR LESS WITH AN ACCURACY OF ABOUT 300 FEET. THE MODEL E-04 ELT MAY BE INSTALLED WITHOUT INTERFACING IT WITH THE

AIRCRAFT GPS SYSTEM, HOWEVER WE STRONGLY RECOMMEND THAT WHEN AVAILABLE THE GPS DATA BE SUPPLIED TO THE ELT. FOR AIRCRAFT WHICH DO NOT HAVE GPS DATA AVAILABLE, THE UNIT CAN BE INTERFACED WITH A LOW COST GPS DATA RECEIVER SUCH AS THE GARMIN GPS 18PC OEM WHICH IS AVAILABLE FOR LESS THAN \$100.00. YOU MUST REGISTER THIS BEACON BEFORE ACTIVATING IT. FAILURE TO DO SO CAN RESULT IN MONETARY FINES, AND OTHER SANCTIONS.

SEE SECTION 8 FOR REGISTRATION INSTRUCTIONS.

YOU MUST UPDATE YOUR REGISTRATION EVERY TWO YEARS.

SECTION 2 ELT INSTALLATION

SEVERAL PROBLEMS ASSOCIATED WITH PREVIOUS TSO C-91, AND C-91a ELT INSTALLATIONS IS THE RESULT OF POORLY CHOSEN MOUNTING LOCATIONS. GENERALLY THE MOST SUITABLE LOCATION FOR FIXED WING AIRCRAFT, IS TO POSITION THE ELT TRANSMITTER IN THE FUSELAGE AS FAR AFT AS POSSIBLE. ANTENNA LOCATION, AND ACCESSIBILITY FOR MAINTENANCE, ARE FACTORS THAT SHOULD BE CONSIDERED WHEN CHOOSING A MOUNTING LOCATION.

THE ELT MUST BE MOUNTED WITH THE ARROW PRINTED ON THE BATTERY CASE POINTING IN THE DIRECTION OF FLIGHT. THE ELT SHOULD BE MOUNTED WITH IT'S LONGITUDINAL AXIS ALIGNED WITHIN 10 DEGREES OF THE LONGITUDINAL AXIS OF THE AIRCRAFT FUSELAGE. AVOID MOUNTING THE ELT NEAR SOURCES OF STRONG EMI/RFI RADIATION.

RTCA DOCUMENT DO-204 PARAGRAPH 3.1.8. PRESCRIBES THE MOUNTING REQUIREMENTS WHICH MUST BE MET WHEN INSTALLING THIS ELT, THESE REQUIREMENTS ARE AS FOLLOWS:

THE ELT SHALL BE MOUNTED TO PRIMARY LOAD-CARRYING STRUCTURES SUCH AS TRUSSES, BULKHEADS, LONGERONS, SPARS, OR FLOOR BEAMS. (NOT AIRCRAFT SKIN.) THE MOUNTS SHALL HAVE A MAXIMUM STATIC LOCAL DEFLECTION NO GREATER THAN 2.5mm (0.1 INCH) WHEN A FORCE OF 450 NEWTONS (100 lbs) IS APPLIED TO THE MOUNT IN THE MOST FLEXIBLE DIRECTION. DEFLECTION MEASUREMENTS SHALL BE MADE WITH REFERENCE TO ANOTHER PART OF THE AIRFRAME NOT LESS THAN 0.3 METER (1 FOOT) NOR MORE THAN 1.0 METER (3 FEET) FROM THE MOUNTING LOCATION.



AFTER SELECTING A SUITABLE LOCATION MEETING ALL OF THE ABOVE REQUIREMENTS. DRILL AND MOUNT THE ELT TRAY ASSEMBLY AS SHOWN IN FIGURE 3. A DOUBLER PLATE MAY BE REQUIRED. SECURE LATCHES WITH TIE WRAP AS SHOWN.

IMPORTANT

THE QUICK RELEASE RETAINING STRAPS WHICH SECURE THE ELT TO THE TRAY ARE SLIGHTLY DIFFERENT IN SIZE. THE STRAP WHICH FITS AROUND THE FRONT OF THE ELT (TRANSMITTER ASSEMBLY) IS MARKED "FRONT." THE STRAP WHICH FITS AROUND THE BATTERY CASE END OF THE ELT IS MARKED "BATTERY."

HELICOPTER INSTALLATION

THE MODEL E-04 ELT IS SUITABLE FOR HELICOPTER INSTALLATION. THE PROCEDURES FOR INSTALLATION, MAINTENANCE, AND OPERATION ARE THE SAME AS FOR FIXED WING AIRCRAFT, EXCEPT FOR THE ORIENTATION OF THE ELT IN RELATION TO THE HELICOPTER LONGITUDINAL AXIS. THE ARROW ON THE BATTERY CASE OF THE ELT SHOULD BE POINTED IN THE NORMAL DIRECTION OF FORWARD FLIGHT. THE LONGITUDINAL SHOULD BE ALIGNED WITHIN +/- 10 DEGREES OF THE LONGITUDINAL AXIS HORIZONTALLY, AND AT A 45 DEGREE DOWNWARD ANGLE AS SHOWN IN FIGURE 2.



SECTION 3 ANTENNA INSTALLATION

IN ORDER TO MEET THE REQUIREMENTS OF TSO C-126, TSO-C91a, AND FAR 91.207 **AN APPROVED ANTENNA MUST BE USED.** THE ANTENNA SUPPLIED WITH THE ELT PART# E-04.8 IS A MONOPOLE DUAL FREQUENCY ANTENNA DESIGN. IT HAS A RECOMMENDED OPERATING SPEED OF UP TO 260 KNOTS. WE ALSO HAVE AVAILABLE A HIGH SPEED BLADE ANTENNA, PART NUMBER S65-1231-1 WHICH IS RATED TO MACH 1.0.

OTHER ANTENNAS MAY BE USED PROVIDED THEY MEET THE MINIMUM VSWR REQUIREMENTS AS NOTED IN THE SPECIFICATIONS SECTION OF THIS MANUAL, (SECTION 12) AND MEET COSPAS/SARSAT APPROVAL FOR USE WITH THE MODEL E-04 ELT. THE COAXIAL CABLE SUPPLIED IS RG-58, AND IS 5 FEET LONG. A LONGER OR SHORTER CABLE MAY BE FABRICATED USING RG-58 OR EQUIVALENT CABLE, AND AMP 227079-5 CONNECTORS. THE INSERTION LOSS OF THE CABLE ASSEMBLY AT 406 MHz SHOULD NOT EXCEED 2 dB. AT 121.5 MHz THE INSERTION LOSS SHOULD NOT EXCEED 3 dB. THE CABLE SHOULD BE A MINIMUM OF 2 FEET IN LENGTH.

THE ANTENNA MAY BE MOUNTED INTERNALLY IN COMPOSITE CONSTRUCTION, AND TUBULAR FABRIC COVERED AIRCRAFT AS LONG AS THE FABRIC OR COMPOSITE MATERIAL IS OF A NON CONDUCTIVE NATURE. THE ANTENNA MUST BE MOUNTED EXTERNALLY ON AIRFRAMES OF METALLIC CONSTRUCTION. THE ANTENNA SHOULD BE MOUNTED AS CLOSE TO THE ELT TRANSMITTER AS PRACTICAL. THE COAXIAL CABLE CONNECTING THE ANTENNA TO THE ELT TRANSMITTER SHOULD NOT BE RUN IN CLOSE PROXIMITY TO COMM RADIO COAXIAL CABLES, AND SHOULD AVOID CROSSING AIRCRAFT PRODUCTION BREAKS (i.e. RIVETED FUSELAGE SECTIONS). THE ANTENNA MUST BE MOUNTED WITHIN 30 DEGREES OF VERTICAL, WHEN THE AIRCRAFT IS IN NORMAL FLIGHT ATTITUDE. THE INSTALLED ANTENNA MUST BE ABLE TO WITHSTAND A STATIC LOAD OF 100 (ONE HUNDRED) TIMES IT'S WEIGHT (13 lbs.) APPLIED TO THE BASE OF THE ANTENNA ALONG THE LONGITUDINAL AXIS OF THE AIRCRAFT. THE ANTENNA SHOULD BE MOUNTED A MINIMUM DISTANCE OF THREE FEET (1 METER) FROM ANY VERTICALLY POLARIZED COMMUNICATION ANTENNAS (i.e. ANTENNAS RADIATING IN THE 118-137 MHz BAND.)

MODEL E-04.8 WHIP ANTENNA


- 1.) DRILL A ½" (13mm) DIAMETER HOLE IN THE AIRCRAFT AT THE ANTENNA MOUNTING LOCATION (FIG 4)
- 2.) INSTALL THE ANTENNA AND DETERMINE IF THE ANTENNA MEETS THE STATIC LOAD REQUIREMENTS. IF NOT A DOUBLER PLATE SHOULD BE FABRICATED.
- 3.) IF THE ANTENNA IS BEING MOUNTED ON A NON CONDUCTIVE PORTION OF THE AIRFRAME, A SUPPLEMENTARY GROUND PLANE MUST BE INSTALLED. THE SUPPLEMENTAL GROUND PLANE MUST HAVE A MINIMUM DIAMETER OF 48" AND MUST BE CENTERED AROUND THE BASE OF THE ANTENNA. THIS MAY BE FABRICATED OUT OF COPPER OR ALUMINUM TAPE. THE TAPE SHOULD BE CUT INTO 6 (SIX) ELEMENTS 24" LONG, AND THE TAPE ELEMENTS SHOULD BE EVENLY SPACED RADIATING IN A CIRCULAR PATTERN FROM THE BASE MOUNTING POINT OF THE ANTENNA. (FIG 4) MAKE SURE ALL ELEMENTS ARE ELECTRICALLY BONDED TO THE BASE OF THE ANTENNA. THE TAPE MAY FOLLOW THE CONTOUR OF THE FUSELAGE. THE METALLIC AIRFRAME OF FABRIC COVERED AIRCRAFT MAY BE USED AS THE GROUND PLANE. WHEN INSTALLING THE ANTENNA, MAKE SURE THE BASE OF THE ANTENNA IS ELECTRICALLY BONDED TO THE TUBING FRAME.

4.) ASSEMBLE THE ANTENNA AS SHOWN IN FIGURE 4. MAKE SURE THE RUBBER WASHER WHICH FORMS A MOISTURE SEAL BETWEEN THE ANTENNA BASE, AND AIRCRAFT STRUCTURE IS IN PLACE BEFORE INSTALLING THE ANTENNA. ALSO MAKE SURE THE SERRATED LOCKING WASHER IS IN PLACE.

IF THE AIRCRAFT SKIN AT THE MOUNTING POINT IS LESS THAN .040" THICK WHEN INSTALLING THE P/N E-04.8 WHIP ANTENNA, A 2" DIAMETER DOUBLER PLATE MUST BE FABRICATED USING .040" THICK 2024, OR 7075 T6 ALUMINUM. (FIGURE 4)

FOR SENSOR SYSTEMS S65-1231-1 HIGH SPEED BLADE ANTENNA INSTALLATION INFORMATION, CONTACT SENSOR SYSTEMS.

WWW.SENSORANTENNAS.COM



ALL WIRE SUPPLIED WITH THE ELT MEETS THE REQUIREMENTS OF FAR 23.1359 AND FAR 23.853 AND MAY BE INSTALLED IN ANY PART 23 CERTIFIED AIRCRAFT

SECTION 4 REMOTE CONTROL INSTALLATION

IMPORTANT YOU MUST INSTALL A BATTERY IN THE REMOTE.

THE REMOTE CONTROL PANEL INDICATOR (RCPI) PART # E-04.5 IS DESIGNED TO BE POWERED BY A SINGLE DURACELL PX28L 6 VOLT LITHIUM BATTERY, OR AN EQUIVALENT. ALKALINE BATTERIES MAY BE USED SUCH AS EVEREADY A 544, OR ITS EQUIVALENT. UNDER NORMAL OPERATING CONDITIONS THE LITHIUM BATTERY MUST BE REPLACED EVERY 10 YEARS. THE ALKALINE BATTERIES MUST BE REPLACED EVERY 5 YEARS. IF THE ELT IS ACTIVATED FOR AN UNKNOWN PERIOD OF TIME, THE BATTERY MUST BE REPLACED. EQUIVALENT CROSS REFERENCE BATTERIES FROM OTHER MANUFACTURERS ARE ACCEPTABLE FOR USE IN THE REMOTE CONTROL.

TO INSTALL OR REPLACE THE RCPI BATTERY FOLLOW THESE STEPS:

- 1.) REMOVE THE THREE RETAINING SCREWS WHICH SECURE THE TOP AND BOTTOM HALF OF THE RCPI UNIT. (FIG 5)
- 2.) REMOVE THE TWO SWITCH RETAINING NUTS LOCATED ON THE FACE OF THE RCPI. THERE ARE TWO PLACARDS SUPPLIED WITH THE REMOTE, (A HORIZONTAL AND A VERTICAL) REMOVE THE PROTECTIVE PLASTIC FILM FROM THE PLACARD FACE AND, INSTALL THE VERTICAL OR HORIZONTAL PLACARD. **CAUTION: THE "ON" POSITION MARKING ON THE PLACARD MUST BE ALIGNED WITH THE RED SWITCH, THE "TEST/RESET" MARKING MUST BE OVER THE BLACK SWITCH.** (FIG 5)
- 3.) CAREFULLY REMOVE THE TOP HALF OF THE RCPI UNIT EXPOSING THE BATTERY COMPARTMENT. (FIG 5) IF REPLACING AN OLD BATTERY, CAREFULLY INSPECT THE BATTERY CONTACTS FOR DIRT OR CORROSION. IF THE CONTACTS NEED CLEANING, USE ONLY NON ABRASIVE ELECTRICAL CONTACT CLEANER, AND A STIFF BRUSH. ABRASIVE CLEANERS WILL REMOVE THE NICKEL AND GOLD PLATING FROM CONTACTS.
- 4.) INSERT THE BATTERY WITH THE POLARITY AS SHOWN IN FIGURE 5. THE POLARITY IS ALSO ENGRAVED ON THE BOTTOM OF THE BATTERY COMPARTMENT.
- 5.) REPLACE THE TOP HALF OF THE RCPI, AND REPLACE THE THREE RETAINING SCREWS AND TWO RETAINING NUTS ON THE FACE OF THE RCPI.
- 6.) THE NEXT RCPI BATTERY REPLACEMENT DATE SHOULD BE RECORDED IN THE AIRCRAFT LOG BOOK WITH A NOTE INDICATING THE BATTERY EXPIRATION DATES.

IMPORTANT: THE RCPI MUST BE MOUNTED SO THAT IT CAN BE SEEN AND OPERATED BY THE PILOT OF THE AIRCRAFT FROM A NORMAL OPERATING POSITION. WE STRONGLY RECOMMEND THAT THE RCPI BE LOCATED WITHIN AN AREA THAT IS PART OF THE PILOTS REGULAR INSTRUMENT SCAN.

5.) MOUNT THE RCPI USING FOUR 4-40 SCREWS, AND NUTS. FIGURE 6 SHOWS THE DIMENSIONS OF THE CUT OUT FOR THE RCPI UNIT. IF THE UNIT IS TO BE MOUNTED IN A LOCATION THAT DOES NOT HAVE A FLUSH MOUNTING SURFACE (i.e. BENEATH THE PANEL GLARE SHIELD.) AN ANGLE BRACKET SHOULD BE FABRICATED. (FIG 6)

PLACARD ORIENTATION



CAUTION

HORIZONTAL AND VERTICAL PLACARDS MUST BE INSTALLED WITH "ON" LABEL ALIGNED WITH THE RED BUTTON





FIGURE 5






FIGURE 6


RCPI UNIT PART # E-04.5




SECTION 5 AUDIO ALERT INDICATOR INSTALLATION

IMPORTANT: THERE IS NO BATTERY INSTALLED IN THE AUDIO ALERT INDICATOR.

REMOVE THE FOUR SCREWS THAT ATTACH THE TOP COVER TO THE AUDIO ALERT INDICATOR P/N E-04.7. INSTALL A DURACELL CR-2, 3 VOLT OR EQUIVALENT BATTERY. MAKE SURE TO OBSERVE THE BATTERY POLARITY (FIG 7). REPLACE THE TOP COVER MAKING SURE THE GRILL PORTION OF THE INDICATOR COVER IS POSITIONED OVER THE BUZZER. THE BATTERY MUST BE REPLACED EVERY 10 YEARS. THE EXPIRATION DATE MUST BE ENTERED IN THE AIRCRAFT AIRFRAME LOG BOOK.



PLUG THE AUDIO ALERT CABLE P/N E-04.10.3 INTO THE RCPI UNIT, AND ONE END OF THE AUDIO ALERT INDICATOR. PLUG THE MALE END OF THE REMOTE CABLE P/N E-04.10.5 IN TO THE OTHER END OF THE AUDIO ALERT UNIT (FIG 8). MOUNT THE AUDIO ALERT UNIT BEHIND THE PANEL USING THE TWO CENTER SCREW ATTACH POINTS, AND 4-40 SCREWS, OR WITH INDUSTRIAL GRADE VELCRO ON THE BACK OF THE AUDIO ALERT (McMASTER CARR 94985K811) OR EQUIVALENT.



SECTION 6 GPS INTERFACE INSTALLATION

THE MODEL E-04 ELT WILL INTERFACE AND RECOGNIZE EIA STANDARD RS 232 DATA FROM NMEA 0183 SOURCES AT 1200, 2400, 4800, AND 9600 BAUD. GARMIN AVIATION FORMAT DATA AT 9600 BAUD, AND BENDIX/KING AVIATION FORMAT DATA AT 9600 BAUD. THE DEFAULT FACTORY SETTING IS: NO JUMPERS INSTALLED, 9600 BAUD.

TO CHANGE THE BAUD RATE, ONE OR TWO JUMPERS ARE INSTALLED ON THE DIGITAL BOARD OF THE ELT. TO ACCOMPLISH THIS REMOVE THE FOUR SCREWS AT THE FRONT OF THE ELT, AND REMOVE THE BATTERY PACK (FIG 9). FIGURE 10 SHOWS HOW TO POSITION THE JUMPER ON THE DIGITAL BOARD FOR THE VARIOUS BAUD RATES. AFTER SELECTING THE DESIRED BAUD RATE, REPLACE THE BATTERY PACK, AND TORQUE THE SCREWS TO 3-4 in-lbs. THE MODEL E-04 ELT IS INTERFACED TO THE AIRCRAFT SOURCE OF NAVIGATION DATA THROUGH A FOUR PIN MINI DIN CONNECTOR. THREE OF THE PINS ARE USED FOR INTERFACING WITH THE AIRCRAFT SYSTEMS, AND THE FOURTH PIN IS USED TO VERIFY THE ELT IS RECEIVING AND PROCESSING THE DATA PROPERLY WHEN INSTALLING THE ELT.

A THREE CONDUCTOR SHIELDED CABLE 24 AWG OR HEAVIER (AIRCRAFT SPRUCE P/N 11-04478 OR EQUIVALENT) SHOULD BE USED TO CONNECT THE ELT RS 232 DATA, AND POWER TO THE AIRCRAFT SYSTEMS. FIGURE 11 SHOWS THE PIN OUTS FOR RS 232 AND POWER INPUT.








FIGURE 9




J1 J2
9600 BAUD
FACTORY
SETTING



J1 J2
4800 BAUD




J1 J2
2400 BAUD



J1 J2
1200 BAUD

- 1.) **DISASSEMBLE THE MINI DIN CONNECTOR, NOTING THE POSITION OF THE PARTS FOR REFERENCE WHEN REASSEMBLING THE CONNECTOR .**
- 2.) **CONNECT ONE CONDUCTOR TO PIN 1 OF THE DIN CONNECTOR, AND TO 10 - 30 VOLTS DC FROM THE AIRCRAFT BUSS. PROTECT THE CIRCUIT WITH A ONE AMP FUSE OR CIRCUIT BREAKER. (FIG 13)**
- 2.) **CONNECT ONE CONDUCTOR TO PIN 3 (FIG 2.1) AND CONNECT TO A/C GROUND AT THE COCKPIT. (FIG 13) CONNECT THE OUTER SHIELD TO GROUND ALSO.**
- 3.) **CONNECT ONE CONDUCTOR TO PIN 4 OF THE DIN CONNECTOR, FOR THE RS 232 OUTPUT FROM THE NAVIGATION EQUIPMENT PROVIDING DATA. MAKE SURE THIS DATA CONFORMS TO ONE OF OUR RECOGNIZED DATA FORMATS, AND BAUD RATES. (FIG 13)**
- 4.) **BRING A SHORT 4" 24 AWG WIRE OUT FROM PIN 2 TO BE USED LATER IN VERIFYING THAT THE ELT IS RECEIVING AND PROCESSING THE GPS DATA PROPERLY. (FIG 12.4)**
- 5.) **SOLDER THE CONNECTIONS, SEAL THE BACK OF THE JACK, AND WIRE SOLDER JOINTS WITH SILICON RTV SEALANT. (LOCTITE 59530 OR EQUIVALENT) (FIG 12.2)**
- 6.) **APPLY RTV SEALANT TO THE INSIDE OF THE OUTER COVER TO SEAL THE WIRE WHERE IT ENTERS THE OUTER HOUSING. (FIG 12.3)**



RS 232 CABLE DIN CONNECTOR PIN FUNCTION	
1	A+ 10-30V DC 40 ma TYP
2	RS 232 SEND
3	GROUND
4	RS 232 REC

FIGURE 11

LOOKING AT
BACK SIDE OF
JACK (SOLDER CUPS)

FIGURE 12





FIGURE 13

SECTION 7 FINAL INSTALLATION AND CHECK OUT


1.) AFTER INSTALLING THE ELT, ANTENNA, AND RCPI IN THE AIRCRAFT. INSTALL THE COAXIAL CABLE BETWEEN THE ELT TRANSMITTER, AND ANTENNA BASE. IF POSSIBLE THE CABLE SHOULD NOT CROSS ANY PRODUCTION BREAKS IN THE AIRFRAME, AND MUST HAVE A REASONABLE AMOUNT OF SLACK AT THE TRANSMITTER. THE SLACK IS NECESSARY FOR EASY REMOVAL OF THE COAXIAL CABLE DURING MAINTENANCE. IF A LONGER CABLE THAN THE ONE SUPPLIED WITH THE UNIT (5 FOOT) IS NEEDED, IT MAY BE FABRICATED USING RG-58 CABLE OR EQUIVALENT, AND AMP 227079-5 CONNECTORS OR THEIR EQUIVALENT. INSERTION LOSS OF THE CABLE AT THE 121.5 MHz FREQUENCY SHOULD NOT EXCEED 3dBm, AND AT THE 406 MHz FREQUENCY 2dBm. SECURE THE COAXIAL CABLE USING TIE WRAPS OR OTHER APPROPRIATE METHODS. MAKE SURE THE CABLE IS PROTECTED FROM ABRASION.

2.) THE RCPI UNIT IS CONNECTED TO THE ELT TRANSMITTER VIA RJ-11 STANDARD TYPE MODULAR CONNECTORS. A 15 FOOT CONNECTING CABLE IS INCLUDED WITH EACH ELT. TO INSTALL THE CABLE, CONNECT THE MODULAR PLUG ON THE ELT TRANSMITTER INTO THE JACK END OF THE INTERCONNECTING CABLE. RUN THE PLUG END OF THE CABLE TO THE AUDIO ALERT UNIT. RUN THE SHORT AUDIO ALERT CABLE FROM THE RCPI TO THE AUDIO ALERT MODULE (PAGE 7 FIG 8) AVOID RUNNING THIS CABLE NEAR SOURCES OF STRONG EMI/RFI RADIATION. (i.e. COMM CABLES, STROBE LIGHT POWER CABLES, STARTER CABLES.) SECURE THE CABLE ALONG ITS RUN USING TIE WRAPS OR OTHER SUITABLE METHODS. THE INTERCONNECTING CABLE MAY BE SHORTENED, OR A LONGER CABLE OF UP TO 150ft. MAY BE USED IF NECESSARY. AFTER CONNECTING THE MINI DIN RS 232 JACK AND PLUG. WRAP ELECTRICAL TAPE AROUND THE JOINT AT THE CENTER OF THE CONNECTOR TO SECURE THE TWO PARTS TOGETHER, AND SEAL THE JOINT FROM MOISTURE. (PAGE 9 FIG 12.5)

3.) AFTER INSTALLATION AND WIRING IS COMPLETE. VERIFY THAT THE ELT IS RECEIVING AND PROCESSING GPS DATA CORRECTLY. APPLY POWER TO BOTH THE ELT, AND THE GPS EQUIPMENT SUPPLYING DATA. MAKE SURE THE GPS HAS A SATELLITE FIX, AND IS REPORTING POSITION DATA. FABRICATE A GPS VERIFICATION TOOL AS SHOWN IN FIGURE 14.

FIGURE 14

GPS DATA VERIFICATION TEST TOOL SCHEMATIC



4.) CONNECT THE TEST TOOL AS SHOWN IN FIG 14. THE MAIN SWITCH ON THE ELT SHOULD BE IN THE “ARMED” POSITION.

5.) WITH POWER SUPPLIED BOTH TO THE ELT, AND THE GPS, MAKE SURE THE GPS HAS ACQUIRED THE SATELLITES, AND IS TRANSMITTING VALID POSITION DATA. THE LED SHOULD BLINK EACH TIME THE ELT RECEIVES A VALID GPS DATA POSITION. (TYPICALLY ONCE PER SECOND.) THIS TEST VERIFIES THAT THE ELT IS PROPERLY RECEIVING, AND PROCESSING POSITION DATA FROM THE GPS SYSTEM.

6.) AFTER VERIFYING THAT THE ELT IS RECEIVING, AND PROCESSING GPS DATA CORRECTLY. SEAL THE END OF THE GPS VERIFICATION TEST LINE USING A ADHESIVE LINED END CAP, (McMASTER-CARR 72855K21) OR OTHER METHOD TO PROTECT IT FROM MOISTURE. SECURE THE TEST WIRE TO THE SHIELDED CABLE WITH A TIE WRAP.

7.) COMPLETE THE STEPS IN SECTION 8 REGISTRATION BEFORE YOU VERIFY THE INSTALLED OPERATION OF THE ELT. AFTER YOU HAVE REGISTERED THE ELT, DO THE SELF TEST AS DESCRIBED IN SECTION 9 TO VERIFY THE COMPLETE SYSTEM IS FUNCTIONING PROPERLY.

8.) RECORD THE ELT BATTERY EXPIRATION DATE MARKED ON THE ELT BATTERY CASE, AND THE EXPIRATION OF THE RCPI, AND AUDIO ALERT BATTERIES IN THE AIRFRAME LOGBOOK.

SECTION 8 REGISTRATION

1.) BEFORE COMPLETING THE FINAL CHECK OUT OF THE ELT, **YOU MUST FIRST REGISTER YOUR BEACON FOLLOWING THE REGISTRATION REQUIREMENTS OF THE COUNTRY WHERE THE AIRCRAFT IS BASED.**

2.) THERE IS A PREPRINTED SELF ADHESIVE LABEL SUPPLIED WITH THE ELT, THAT HAS THE HEX CODE, MANUFACTURER, AND MODEL NUMBER ON IT WHICH YOU SHOULD AFFIX TO THE TOP OF THE REGISTRATION FORM. OR YOU CAN REFER TO THIS LABEL WHEN REGISTERING OVER THE INTERNET. YOU CAN DOWNLOAD THE REGISTRATION FORMS FOR YOUR COUNTRY FROM OUR WEBSITE.
WWW.ACKAVIONICS.COM

3.) IN THE US AND CANADA YOU CAN MAIL OR FAX THE REGISTRATION FORMS HOWEVER IT IS STRONGLY RECOMMEND THAT BEACON REGISTRATION BE COMPLETED ON LINE AT THE FOLLOWING SITES:

UNITED STATES

www.beaconregistration.noaa.gov

CANADA

www.canadianbeaconregistry.forces.gc.ca


4.) FOR OTHER COUNTRIES CONTACT THE COSPAS/SARSAT REGULATING BODY FOR REGISTRATION INSTRUCTIONS. IF ALLOWED BY YOUR REGULATING COUNTRY YOU MAY REGISTER AT THE COSPAS/SARSAT WEBSITE.

INTERNATIONAL

www.406registration.com

5.) WHEN FILLING OUT THE REGISTRATION THE HEX CODE IDENTIFIER MAY ALSO BE FOUND ON THE FRONT RIGHT SIDE OF THE ELT. (FIG 15)

6.) **YOU MUST UPDATE YOUR BEACON REGISTRATION** EVERY TWO YEARS, AND ANY TIME THE BEACON IS USED IN A DIFFERENT AIRCRAFT.



SECTION 9 OPERATION AND SELF TEST

THERE ARE THREE MODES IN WHICH THE ELT MAY BE ACTIVATED:

- 1.) THE ELT AUTOMATICALLY ACTIVATES WHEN IN THE “ARMED” POSITION, AND A CRASH LEVEL DECELERATION FORCE IS APPLIED TO THE ELT IN THE FORWARD DIRECTION AS INDICATED BY THE ARROW ON THE TOP OF THE BATTERY PACK.
- 2.) THE ELT ALSO MAY BE ACTIVATED BY PRESSING THE “ON” BUTTON ON THE COCKPIT REMOTE CONTROL (RCPI). (FIG 16)
- 3.) A THIRD METHOD OF ACTIVATING THE ELT, IS BY MEANS OF PLACING THE MAIN ON-OFF-ARMED SWITCH ON THE FRONT OF THE ELT IN THE “ON” POSITION. (FIG 17)

THE RUBBER COVER COVERING THE MAIN SWITCH ON THE ELT **SHOULD BE LEFT OFF AT ALL TIMES, EXCEPT WHEN THE ELT IS IN THE ARMED POSITION.** THE COVER HAS A CENTER CONE, WHICH PROJECTS DOWN INTO THE SWITCH RECESS, AND PROVIDES FOR POSITIVE RETENTION OF THE SWITCH IN THE ARMED POSITION.

THERE ARE TWO MODES IN WHICH THE ELT MAY BE DEACTIVATED.

- 1.) PRESSING THE “RESET” BUTTON ON THE REMOTE CONTROL (RCPI). (FIG16)
- 2.) PLACING THE MAIN SWITCH ON THE ELT IN THE “OFF” POSITION. (FIG 17)

WHEN THE ELT IS IN THE ACTIVE MODE, (TRANSMITTING) THE COCKPIT REMOTE WILL FLASH, AND THE AUDIO ALERT INDICATOR WILL EMMITT A SERIES OF 9 BEEPS APPROXIMATELY EVERY 50 SECONDS TO ALERT THE CREW THAT THE ELT IS OPERATING. IF THERE IS NO EMERGENCY, RESET THE ELT USING THE "RESET" BUTTON ON THE REMOTE, AND IMMEDIATELY NOTIFY THE APPROPRIATE SEARCH AND RESCUE OPERATIONS OFFICE, OR ATC OF THE FALSE ACTIVATION. (FIG 16)



SELF TESTS:

THE ELT IS CAPABLE OF PERFORMING A SELF TEST TO VERIFY THAT MAJOR ELT SYSTEMS ARE FUNCTIONING PROPERLY.

DURING THE SELF TEST, THE ELT TRANSMITS ON 121.5 MHz FOR 1 SECOND, (3 AUDIO SWEEPS) THEN TRANSMITS A 406 MHz TEST BURST FOR 550ms THEN RETURNS TO THE ARMED MODE.

THERE ARE TWO MODES IN WHICH A SELF TEST CAN BE INITIATED:

- 1.) WHEN THE ELT IS IN THE "ARMED" POSITION, PRESSING THE "RESET/TEST" SWITCH ON THE COCKPIT REMOTE CONTROL (RCPI) INITIATES A SELF TEST. (FIG 16)
- 2.) WHEN THE MAIN SWITCH OF THE ELT IS MOVED FROM THE "OFF" POSITION TO THE "ARMED" POSITION, IT DOES A SELF TEST. THIS MODE IS PRIMARILY DESIGNED TO PROVIDE FOR A METHOD TO BENCH TEST THE ELT WITH THE REMOTE CONTROL DISCONNECTED. (FIG 17)



YOU MUST PERFORM A SELF TEST EVERY THREE MONTHS TO VERIFY THE ELT IS FUNCTIONING PROPERLY.

TO PERFORM THE SELF TEST, MAKE SURE THE AIRCRAFT MASTER SWITCH IS OFF AND THERE IS NO POWER APPLIED TO THE ELT THROUGH THE GPS INTERFACE.

WITH THE ELT MAIN SWITCH IN THE "ARMED" POSITION, AND NOT OPERATING, PRESS THE "RESET/TEST" BUTTON ON THE COCKPIT REMOTE CONTROL (RCPI) ONCE.

THE LIGHT WILL FLASH ON THE REMOTE AND YOU WILL HEAR ONE BEEP FROM THE AUDIO ALERT INDICATOR IF ALL SYSTEMS ARE FUNCTIONING PROPERLY.

A SERIES OF 2 –5 BEEPS INDICATES THERE IS A SELF TEST FUNCTION THAT HAS RETURNED A TROUBLE CONDITION. THE ELT WILL NOT BE DISABLED BUT IT SHOULD BE INSPECTED BY A QUALIFIED AVIONICS FACILITY AS SOON AS POSSIBLE.

THE TROUBLE CODE RETURNS A SERIES OF BEEPS WITH A TWO SECOND DELAY, AND THEN THE TROUBLE CODE IS REPEATED ONE MORE TIME. THE FIRST BEEPS ALERT YOU THAT THERE IS A TROUBLE CONDITION. THE TWO SECOND DELAY IS TO ALLOW YOU TO BE READY TO COUNT THE SECOND SET OF BEEPS.

TROUBLE CODE SEQUENCE: 2-5 BEEPS — TWO SECOND DELAY — 2-5 BEEPS

TROUBLE CODES:

2 BEEPS → BATTERY LOW

3 BEEPS → LOW RF POWER

4 BEEPS→ FREQUENCY NOT LOCKED

5 BEEPS→ HIGH VSWR OR HIGH CURRENT

SECTION 10 PERIODIC MAINTENANCE/CONTINUING AIRWORTHINESS

THE FOLLOWING TEST MUST BE PERFORMED A MINIMUM OF EVERY THREE CALENDAR MONTHS.

ELT SELF TEST FUNCTION AS DESCRIBED IN SECTION 9 OF THIS MANUAL.

THE FOLLOWING TESTS MUST BE PERFORMED A MINIMUM OF EVERY TWELVE CALENDAR MONTHS, TO ASSURE THE CONTINUING AIRWORTHINESS OF THE ELT.

- 1.) **INSPECT THE ELT TRANSMITTER AND MOUNTING TRAY TO INSURE ALL FASTENERS AND MECHANICAL ASSEMBLIES ARE SECURE.**
- 2.) **INSPECT THE COAXIAL CABLE CONNECTING THE ELT TRANSMITTER TO THE ANTENNA FOR CUTS OR ABRASIONS ON IT'S OUTER JACKET. DISCONNECT THE BNC CONNECTOR AT EACH END. EXAMINE BOTH BNC CONNECTORS AND THE MATING PLUG ON THE ELT TRANSMITTER, AND ANTENNA BASE FOR ANY SIGNS OF CORROSION.**
- 3.) **INSPECT THE MODULAR CABLE CONNECTING THE ELT TO THE RCPI UNIT FOR SIGNS OF WEAR OR ABRASION ON IT'S OUTER JACKET. REMOVE THE MODULAR PLUG CONNECTING THE ELT TRANSMITTER TO THE CONNECTING CABLE, AND INSPECT THE JACK AND PLUG ASSEMBLY FOR CORROSION.**
- 4.) **IF A GPS IS INTERFACED TO THE ELT, INSPECT THE MODULAR CABLE CONNECTING THE ELT TO THE GPS UNIT FOR SIGNS OF WEAR OR ABRASION ON IT'S OUTER JACKET. REMOVE THE MODULAR PLUG CONNECTING THE ELT TRANSMITTER TO THE GPS AND INSPECT THE JACK AND PLUG ASSEMBLY FOR CORROSION.**
- 5.) **CHECK THE EXPIRATION DATE OF THE RCPI BATTERY, AND AUDIO ALERT BATTERY IN THE AIRCRAFT LOG BOOK. ALSO CHECK THE EXPIRATION DATE OF THE BATTERY PACK, AND REPLACE IF NECESSARY.**
- 6.) **LEAVE THE ELT IN THE "ARMED" POSITION, THEN REMOVE THE ELT FROM THE AIRCRAFT AND PERFORM A G SWITCH TEST AS FOLLOWS:**

THIS TEST SHOULD BE CONDUCTED BETWEEN THE HOUR, AND 5 MINUTES AFTER THE HOUR PER FCC REQUIREMENTS. TUNE AN AIRCRAFT RADIO, OR HAND HELD AIRCRAFT RADIO TO 121.5 MHz. THE RADIO SHOULD BE IN CLOSE PROXIMITY TO THE AREA WHERE YOU WILL CONDUCT THE TEST. **TURN THE SQUELCH CONTROL ALL THE WAY DOWN OR OFF. YOU SHOULD BE HEARING WHITE NOISE ON THE RADIO.**

WHILE IN THE "ARMED" POSITION, HOLD THE ELT AT YOUR WAIST WITH THE ARROW PRINTED ON THE BATTERY CASE FACING AWAY FROM YOU. MOVE THE ELT RAPIDLY AWAY FROM YOUR WAIST. WHEN THE ELT REACHES THE FULL EXTENT OF YOUR ARM RETRACT IT BACK TO YOUR WAIST AS FAST AS POSSIBLE. YOU SHOULD HEAR THE 121.5 MHz SWEEP TONE IN THE RADIO. **AS SOON AS YOU HEAR THE TONE IMMEDIATELY TURN THE MAIN SWITCH ON THE ELT TO THE "OFF" POSITION.**

THE ELT WHEN ACTIVATED TRANSMITS ON 121.5 MHz FOR APPROXIMATELY 50 SECONDS BEFORE A 406 MHz BURST IS SENT TO THE SATELLITES. THIS IS A LIVE BURST WHICH WILL IMMEDIATELY NOTIFY THE COSPAS/SARSAT SYSTEM THAT THERE IS AN EMERGENCY. **IT IS IMPERATIVE THAT YOU DO NOT ALLOW AN ACTIVATED ELT TO TRANSMIT FOR MORE THAN 30 SECONDS DURING G SWITCH TESTING.**

7.) **REINSTALL THE ELT AND MAKE SURE THE CABLES ARE SECURED AND PROPERLY CONNECTED. MAKE SURE TO SEAL THE DIN CONNECTOR IF THE ELT IS CONNECTED TO THE AIRCRAFT GPS. (PAGE 9 FIG 12.5) PLACE THE MAIN SWITCH IN THE "ARMED" POSITION AND INSTALL THE RUBBER COVER OVER THE MAIN SWITCH OPENING.**

8.) **PERFORM A SELF TEST DESCRIBED IN SECTION 9 TO VERIFY PROPER OPERATION.**

SECTION 11 E-04.0 LITHIUM BATTERY REPLACEMENT

THE LITHIUM BATTERY (P/N E-04.0) MUST BE REPLACED ON OR BEFORE THE BATTERY EXPIRATION DATE MARKED ON THE BATTERY. IT IS NO LONGER AIRWORTHY AFTER THIS DATE. SEE FAR 91.207 FOR OTHER ELT REQUIREMENTS.

REPLACEMENT OF THE MAIN LITHIUM BATTERY P/N E-04.0

- 1.) USING A 3/32 HEX WRENCH REMOVE THE FOUR RETAINING SCREWS THAT ATTACH THE BATTERY CASE TO THE ELT TRANSMITTER ASSEMBLY, AND GENTLY PULL THE BATTERY PACK FROM THE TRANSMITTER SECTION. (FIG 9 PAGE 8)
- 2.) **WITH THE MAIN SWITCH IN THE "OFF" POSITION**, INSTALL THE NEW SEALED BATTERY PACK. (PART# E-04.0) THE BATTERY PACK IS DESIGNED SO THE BATTERY CAN ONLY BE INSTALLED IN THE PROPER ORIENTATION. WET THE O-RING WITH A MILD DISH SOAP SOLUTION, AND SHAKE OFF THE EXCESS SOLUTION, OR USE SILICON VACUUM GREASE. INSTALL THE O-RING ONTO THE BATTERY CASE. REMOVE THE TWO PROTECTIVE CAPS FROM THE BATTERY CONTACTS. (FIG 18) THE BATTERY PACK SHOULD SLIDE EASILY INTO THE TRANSMITTER HOUSING.
- 3.) RE-ATTACH THE TRANSMITTER ASSEMBLY TO THE BATTERY PACK BY REPLACING THE FOUR HEX HEAD SCREWS. TIGHTEN THE SCREWS TO 3.5-4.0 in-lbs.
- 4.) RECORD THE NEW BATTERY EXPIRATION DATE IN THE AIRFRAME LOGBOOK.
- 5.) AFTER RE-INSTALLATION OF THE ELT INTO THE AIRCRAFT, A SELF TEST MUST BE PERFORMED. REFER TO SECTION 9.

THE FOLLOWING IS AN EXCERPT FROM FAA AC 91-44A PARAGRAPH 8.a WHICH DEFINES WHEN ELT BATTERY REPLACEMENT MAY BE DONE UNDER 14 CFR PART 43.3(h) AS PREVENTIVE MAINTENANCE.

"...THE REPLACEMENT CAN BE DONE BY THE PILOT IF THE PREVENTIVE MAINTENANCE LIMITATIONS OF PART 43.3(h) OF THE FAR, ARE COMPLIED WITH. FOR EXAMPLE, A PORTABLE TYPE ELT THAT IS READILY ACCESSIBLE AND CAN BE REMOVED AND REINSTALLED IN THE AIRCRAFT BY A SIMPLE OPERATION SHOULD BE CONSIDERED PREVENTIVE MAINTENANCE. FIXED TYPE ELT INSTALLATIONS ARE OFTEN PERMANENTLY MOUNTED IN A REMOTE AREA OF THE AIRCRAFT NEAR FLIGHT CONTROL CABLES, VITAL AIRCRAFT COMPONENTS, AND CRITICAL ATTACHMENTS TO THE AIRCRAFT STRUCTURE. INSTALLATIONS OF THIS NATURE REQUIRE AN EXTERNAL ANTENNA AND OFTEN A REMOTE ON/OFF TRANSMITTER CONTROL SWITCH THAT IS USUALLY LOCATED NEAR THE PILOTS FLIGHT POSITION. THIS TYPE OF INSTALLATION IS COMPLEX AND BATTERY REPLACEMENT SHOULD BE ACCOMPLISHED BY A CERTIFIED MECHANIC OR CERTIFIED REPAIR STATION..."

BATTERY AND ELT DOT/ IATA SHIPPING INFORMATION

THE ELT WITH THE BATTERY ATTACHED IS A DOT/IATA CLASS 9 HAZMAT MATERIAL UNDER THE CATEGORY OF LIFE SAVING APPLIANCES NOT SELF INFLATING UN 3072. **THERE ARE NO AIR SHIPMENT RESTRICTIONS FOR SUCH DEVICES, AND THEY MAY BE SHIPPED IN ANY QUANTITY IN PASSENGER CARRYING OR TRANSPORT AIRCRAFT.**

THE ORIGINAL ACK ELT SHIPPING BOX IS CERTIFIED TO COMPLY WITH UNITED NATIONS PACKAGING SPECIFICATIONS. (UN)

THE BATTERY WHEN SHIPPED ALONE IS A CLASS 9 HAZMAT UNDER THE CATEGORY OF LITHIUM BATTERIES UN 3090. IF THE TOTAL WEIGHT OF THE SHIPMENT EXCEEDS 5 kg THEY ARE RESTRICTED FROM CARRIAGE IN PASSENGER CARRYING AIRCRAFT.



ELT PART NUMBER E-04

APPROVALS:

FAA / TRANSPORT CANADA
TSO C-126 TSO C-91a
ETSO 2C126 ETSO 2C91a
COSPAS/SARSAT T.001 T.007
INDUSTRY CANADA 1863A-E04AF

TYPE:

TSO C-126 AF

FREQUENCY:

121.5 MHz & 406.037 MHz

MODULATION:

406 MHz +/-2 kHz Bi-Phase L (16KOG1D)
121.5 MHz +/- 6 kHz AM (3K20A3N)
SWEPT DOWNWARD 1400 – 400 Hz
REPETITION RATE 3 Hz
MODULATION FACTOR ≥ 90%
DUTY CYCLE ≥ 45%

POWER AT TERMINAL 50 Ω LOAD:

121.5 MHz 20.7 dBm 50 HOURS@ -20C
406.037 MHz 37.3 dBm 24.5 HOURS @ -20C
STANDBY CURRENT ARMED MODE 26 uA
PEAK CURRENT 406 MHz BURST 1.5 –2 A
CURRENT 121.5 MHz OPERATION 75 mA
PEAK EIRP WITH E-04.8 WHIP ANTENNA
AND E-04.10.4 COAX CABLE:
121.5 MHz +23 dBm 200 mW
406.037 MHz +39.79 dBm 13.7 W

OPERATING TEMPERATURE:

-20C TO +55C

STORAGE TEMPERATURE:

-55C TO +85C

CRASH ACTIVATION:

4.5 FpS +/- .5 FpS

DIMENSIONS:

7.750" x 2.850" x 2.850"
192 mm x 72 mm x 72 mm

WEIGHT:

ELT AND BATTERY PACK 1.6 lbs .73kg
ELT TRAY AND STRAPS .2 lbs .09kg
REMOTE CONTROL (RCPI) 1.1 oz 31g
AUDIO ALERT INDICATOR 1.5 oz 43g

ANTENNA PART NUMBER E-04.8

LENGTH 20.625" 524 mm SWEPT 20°

WEIGHT 2.1 oz 60g

IMPEDANCE 50 OHM NOMINAL

VSWR @ 121.5 MHz ≤ 2.0:1

VSWR @ 406 MHz ≤ 1.4:1

MAX AIRSPEED 260 KNOTS@ SEA LEVEL

BATTERY PART NUMBER E-04.0

APPROVALS:

FAA / TRANSPORT CANADA
TSO C-142a
ETSO C-142a

TYPE:

Li-SO2
NON FLAMMABLE ELECTROLYTE

VOLTAGE:

12 VOLTS

OPERATING TEMPERATURE:

-20C TO +55C

DIMENSIONS:

5.750" x 2.850" x 2.850"
146mm x 72mm x 72mm

WEIGHT:

1.18 lbs .535 kg

AMP HOUR RATING:

7.75 Ah

NON RECHARGEABLE

LITHIUM CONTENT:

9.8 GRAMS

MAXIMUM DISCHARGE RATE:

2.5 AMPS

BATTERY LIFE:


5 YEARS

WHEN USED WITH THE MODEL E-04 ELT

LIMITATIONS: ANY OTHER USE OF THIS BATTERY IN AIRCRAFT IS PROHIBITED UNLESS APPROVED BY ACK TECHNOLOGIES INC.

THE CONDITIONS AND TESTS FOR TSO APPROVAL OF THIS ARTICLE ARE MINIMUM PERFORMANCE STANDARDS. THOSE INSTALLING THIS ARTICLE, ON OR IN A SPECIFIC TYPE OR CLASS OF AIRCRAFT, MUST DETERMINE THAT THE AIRCRAFT INSTALLATION CONDITIONS ARE WITHIN THE TSO STANDARDS. TSO ARTICLES MUST HAVE SEPARATE APPROVAL FOR INSTALLATION IN AN AIRCRAFT. THE ARTICLE MAY BE INSTALLED ONLY ACCORDING TO 14 CFR PART 43 OR THE APPLICABLE AIRWORTHINESS REQUIREMENTS. LITHIUM CELL AND BATTERY SAFETY CONCERNS INCLUDE THE POSSIBILITY OF FIRE AND VENTING OF TOXIC GASES

E-04 ELT MAJOR PARTS



SECTION 13 PROGRAMMING

THE ELT IS FACTORY PROGRAMMED TO THE STANDARD LOCATION SERIAL NUMBER
FORMAT WITH U.S.A. COUNTRY CODE. (366)

THE ELT MAY BE PROGRAMMED IN THE FIELD TO THE FOLLOWING FORMATS:
SERIAL NUMBER (YOU MAY ONLY REPROGRAM THE COUNTRY CODE IN THIS FORMAT.)

STANDARD LOCATION 24-BIT ADDRESS

STANDARD LOCATION WITH OPERATOR DESIGNATOR & SERIAL NUMBER

TO REPROGRAM THE ELT YOU MUST USE OUR PROGRAMMING DONGLE.
(P/N E-04.PRG V 2.0) THE MODULE INTERFACES TO A PC OPERATING WINDOWS XP,
WINDOWS 7, OR WINDOWS VISTA VIA A USB PORT.
THE PROGRAMMING SOFTWARE AND MANUAL MAY BE DOWNLOADED FROM OUR WEB
SITE WWW.ACKAVIONICS.COM.

SECTION 14 WARRANTY PROCEDURE

SHOULD IT BECOME NECESSARY TO RETURN THE ELT FOR WARRANTY SERVICE.
REMOVE THE ELT BATTERY BEFORE SHIPPING THE UNIT TO OUR FACILITY. THE
BATTERY IS **DOT/IATA CLASS 9 HAZARDOUS MATERIAL** AND DOT/IATA REGULATIONS
MUST BE FOLLOWED WHENEVER SHIPPING THE BATTERY, OR ELT AND BATTERY.
SEE SECTION 11 PAGE 14 FOR ADDITIONAL SHIPPING INFORMATION.

ALL UNITS MUST BE RETURNED TO OUR FACILITY FREIGHT PREPAID. OUR SHIPPING
ADDRESS IS AS FOLLOWS:

ACK TECHNOLOGIES, INC.
440 W. JULIAN ST.
SAN JOSE, CA 95110

MAKE SURE THAT YOU HAVE INCLUDED PAPERWORK WITH A RETURN ADDRESS THAT
IS SUITABLE FOR UPS RETURN SHIPMENT. (NO P.O. BOXES OR APO NUMBERS.)
PLEASE INCLUDE A SHORT DESCRIPTION OF THE PROBLEM YOU HAVE BEEN
EXPERIENCING, AND A TELEPHONE NUMBER WHERE YOU MAY BE REACHED DURING
BUSINESS HOURS IF POSSIBLE. NO RMA NUMBER IS REQUIRED.

ANY UNIT THAT IS RETURNED FOR WARRANTY AND FOUND NOT TO BE DEFECTIVE
WILL BE CHARGED A MINIMUM HANDLING AND SERVICE CHARGE AND RETURNED
C.O.D.

RECORD YOUR AIRCRAFT AND ELT INFORMATION FOR FUTURE REFERENCE

AIRCRAFT _____

REGISTRATION NUMBER _____ COUNTRY _____

INSTALLATION DATE _____

ELT SERIAL NUMBER (FROM TSO LABEL) _____

ELT HEX CODE (FROM RIGHT SIDE LABEL) _____

UPDATE REGISTRATION EVERY TWO YEARS

NEXT REG DUE

SECTION 15 DO-160F/ED-14F ENVIRONMENTAL CATEGORIES

CONDITIONS	SECTION	DESCRIPTION OF TESTS CONDUCTED
<i>Temperature and Altitude</i>	<i>4.0</i>	<i>Qualifies To Category D1</i>
<i>Temperature Variation</i>	<i>5.0</i>	<i>Qualifies To Category A</i>
<i>Humidity</i>	<i>6.0</i>	<i>Qualifies To Category C</i>
<i>Shock and Crash DO-204 Par. 2.3.4.1 DO-204 Par. 2.4.2.4</i>	<i>7.0</i>	<i>Not Tested Category Identified as X Shock Crash Safety</i>
<i>Vibration</i>	<i>8.0</i>	<i>Qualifies To Category R</i>
<i>Explosive Atmosphere</i>	<i>9.0</i>	<i>Not Tested Category Identified as X</i>
<i>Waterproofness</i>	<i>10.0</i>	<i>Qualifies To Category S</i>
<i>Fluids Susceptibility</i>	<i>11.0</i>	<i>Not Tested Category Identified as X</i>
<i>Sand and Dust</i>	<i>12.0</i>	<i>Not Tested Category Identified as X</i>
<i>Fungus</i>	<i>13.0</i>	<i>Not Tested Category Identified as X</i>
<i>Salt Spray</i>	<i>14.0</i>	<i>Qualifies To Category S</i>
<i>Magnetic Effect</i>	<i>15.0</i>	<i>Qualifies To Category Z</i>
<i>Power Input</i>	<i>16.0</i>	<i>Qualifies To Category B Additional Testing to 16.6.1.3 (b)</i>
<i>Voltage Spike</i>	<i>17.0</i>	<i>Qualifies to Category B</i>
<i>Audio Frequency Conducted Susceptibility</i>	<i>18.0</i>	<i>Qualifies To Category B</i>
<i>Induced Signal Susceptibility</i>	<i>19.0</i>	<i>Qualifies To Category BC</i>
<i>Radio Frequency Susceptibility</i>	<i>20.0</i>	<i>Not Tested Category Identified as X</i>
<i>Radio Frequency Emissions</i>	<i>21.0</i>	<i>Qualifies To Category H</i>
<i>Lightning Induced Transient susceptibility</i>	<i>22.0</i>	<i>Not Tested Category Identified as X</i>
<i>Lightning Direct Effects</i>	<i>23.0</i>	<i>Not Tested Category Identified as X</i>
<i>Icing</i>	<i>24.0</i>	<i>Not Tested Category Identified as X</i>
<i>Electro-Static Discharge</i>	<i>25.0</i>	<i>Not Tested Category Identified as X</i>
<i>Fire, Flammability DO-204 Par. 2.3.7.1</i>	<i>26.0</i>	<i>Not Tested Category Identified as X Flame Test</i>

Additional DO-204 Testing

DO-204	Par 2.3.2.1	Low Temperature Battery Life
DO-204	Par 2.3.2.2	High Temperature Battery Life
DO-204	Par 2.3.2.3	Frequency Stability With Temperature Gradient
DO-204	Par 2.3.2.4	Thermal Shock
DO-204	Par 2.3.2.5	VSWR
DO-204	Par 2.3.2.6	Self Test
DO-204	Par 2.3.1.1	Low Temperature Activation
DO-204	Par 2.3.1.2	High Temperature Activation
DO-204	Par 2.3.1.3	Altitude
DO-204	Par 2.3.1.4	Decompression
DO-204	Par 2.3.1.5	Overpressure

SECTION 16 CANADIAN MAINTENANCE REQUIREMENTS

IN ADDITION TO OUR PERIODIC MAINTENANCE REQUIREMENTS OF SECTION 10 IN CANADA YOU MUST COMPLY WITH CAR PART 5, CHAPTER 571, APPENDIX G MAINTENANCE REQUIREMENTS FOR CONTINUED AIRWORTHINESS. WE STRONGLY RECOMMEND THE "WS TECHNOLOGIES INC" BT100AV, OR BT100AVS TESTER BE USED TO VERIFY THE PERFORMANCE CHARACTERISTICS OF THE ELT.

WEBSITE: WWW.WST.CA

THESE TESTS SHOULD ONLY BE PREFORMED IN A RF SCREEN ROOM.

WHEN USING CONVENTIONAL TEST EQUIPMENT TO PERFORM THIS TEST:

CONNECT THE RF OUTPUT OF THE ELT TO A SPECTRUM ANALYZER WITH A 50 OHM IMPEDANCE CAPABLE OF MEASURING FREQUENCY, POWER, AND PERFORM THE FOLLOWING TESTS. **THE OUTPUT POWER DURING THE 406 MHz BURST IS + 37 dBm MAKE SURE THIS DOES NOT EXCEED THE MAXIMUM INPUT LEVEL OF THE ANALYZER.** AN ATTENUATOR MAY BE NECESSARY TO REDUCE THE INPUT POWER TO THE ANALYZER. THE TEST RESULTS MUST FALL WITHIN THE FOLLOWING MINIMUM AND MAXIMUM VALUES:

406 FREQUENCY: 406.037000 MHz +/- 2 kHz

POWER: 35—39 dBm

121.5 MHz FREQUENCY: 121.5 MHz +/- 6 kHz

POWER: + 17-23 dBm

THE CURRENT DRAW REQUIREMENTS OF THE REGULATIONS MAY BE CONFIRMED BY REMOVING THE BATTERY CASE, SEPARATING IT FROM THE TRANSMITTER HEAD AND USING JUMPERS TO CONNECT THE BATTERY IN SERIES WITH THE CURRENT METER.

CAUTION: THE POWER INPUT IS NOT PROTECTED FROM REVERSE POLARITY. IF REVERSE POLARITY IS APPLIED SEVERE DAMAGE WILL OCCUR AND VOID THE WARRANTY.

STANDBY CURRENT IN THE ARMED MODE: 26 uA +/- 4 uA

THE G SWITCH ACTIVATION REQUIRED BY CAR PART 5, CHAPTER 571, APPENDIX G PAR (c) (3) (e) IS PREFORMED DURING THE SECTION 10 TESTING AND INSPECTION.

LIMITED WARRANTY

THIS MODEL E-04 EMERGENCY LOCATOR TRANSMITTER IS GUARANTEED BY ACK TECHNOLOGIES, INC. AGAINST DEFECTS IN MATERIALS AND WORKMANSHIP FOR A PERIOD OF TWO YEARS FROM THE INSTALLATION DATE OR TWO YEARS THREE MONTHS FROM THE DATE IT WAS MANUFACTURED WHICHEVER OCCURS FIRST. ACTIVATE YOUR WARRANTY BY REGISTERING ON LINE AT OUR WEBSITE WWW.ACKAVIONICS.COM THIS WARRANTY IS LIMITED EXCLUSIVELY TO REPAIR OR REPLACEMENT OF THE E-04 ELT AND ASSOCIATED PARTS WHICH WERE MANUFACTURED BY ACK TECHNOLOGIES, INC. THE DEFECTIVE PARTS MUST BE RETURNED FREIGHT PREPAID TO OUR MANUFACTURING FACILITY. THIS WARRANTY DOES NOT INCLUDE REPAIR OR REPLACEMENT OF ANY PART THAT HAS BEEN IMPROPERLY USED, INSTALLED OR PHYSICALLY DAMAGED. THIS WARRANTY DOES NOT COVER ANY DAMAGE DONE BY CHEMICAL EXPOSURE TO THE ELT. EXCEPT AS PROVIDED HEREIN ACK TECHNOLOGIES, INC. MAKES NO EXPRESS WARRANTIES, AND ANY IMPLEMENTED WARRANTY OF MERCHANTABILITY OF FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES SET FORTH HEREIN. ACK TECHNOLOGIES, INC. SHALL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR MISUSE OF THIS PRODUCT. EXCEPT AS PROVIDED HEREIN NO EMPLOYEE, AGENT, DEALER, OR OTHER PERSON IS AUTHORIZED TO GIVE ANY WARRANTIES OF ANY NATURE ON BEHALF OF ACK TECHNOLOGIES, INC.

YOU MAY HAVE ADDITIONAL LEGAL RIGHTS WHICH VARY FROM STATE TO STATE

**ACK TECHNOLOGIES
INC.**

AVIONICS FOR GENERAL AND COMMERCIAL AVIATION
440 W. JULIAN STREET SAN JOSE, CA 95110
408 287-8021 Fax 408 971-6879

PHONE (408) 287-8021
FAX (408) 971-6879

HOURS OF OPERATION 9:00am—5:00pm PST

WEBSITE: WWW.ACKAVIONICS.COM
E-MAIL: INFO@ACKAVIONICS.COM